

Installation Instructions P.V.C. Drip Line Start Connectors

Step 1

Drill hole:

- For P.V.C. 16 mm or 16.5 mm.
- For P.E. 15.5 mm.
- TAVLIT recommends using for specialty drills the grommet drill, cat code GD155, GD160, GD165.
- Warning: Imperial/American size drills may not be appropriate and may compromise the assembly (For example 5/8" drill bit).



Step 1

Step 2

- Insert rubber grommet.



Step 2

Step 3

- Moisten Starter.
- Use only water based lubricants (No Soap suds).



Step 3

Step 4

- Insert starter with P.V.C. start assembler by pushing without twisting or turning.



Step 4

Step 5

- Push leader pipe or barb connector.
- Do not twist or turn the starter.